



Inspect Tool Before Use Tool Under Pressure

PLEASE READ AND FOLLOW INSTRUCTIONS FOR BEST RESULTS

1. Make Sure Valve handle is in closed position. Handle must be perpendicular to valve. (90 degree angle).
2. Unscrew lid and remove clear plastic reservoir. Inspect for cracking, chips, damages. Inspect thread for cross-threading or damages. Ensure O-ring is placed in groove on main portion of tool and is not damaged.
3. Fill clear reservoir with desired amount of Counteract Balancing Beads.
4. Re-attach reservoir to main portion of tool in up-right position. Ensure flat edge of the clear plastic reservoir is clean of dirt and debris. Hand tighten reservoir to main portion of tool.
5. Ensure valve handle is in closed position. Attach airline to the tool.

Closed



Opened



6. Position valve-stem at 12 o'clock (top of tire) Remove valve-core from the tire's valve-stem. Allow tire to deflate to approximately half of it's PSI. Do not deflate fully.



7. Attach the clip-on air chuck to valve-stem. Keep reservoir pointing down in the 6 o'clock position. Open valve to allow air-flow. As beads are injected into tire, slowly turn reservoir to horizontal position. Continue to turn reservoir, until the reservoir is in the 3 o'clock position. Funneling beads into the air path.



8. The air injection should only take 20 seconds to 40 seconds. Ensure feed-line is clear. Remove clip-on chuck. Close air-valve on injection tool.
9. Air the tire up. Install valve-core. Top-up air pressure to desired PSI.



Troubleshooting Guide

Outlet hose clogging during injection process:

- Valve core was not removed, verify valve core was removed and not damaged or partially removed.
- Beads are being fed into injector too quickly. To fix, leave injector's valve open, disconnect air-line to injector. Leave clip-on chuck connected to valve-stem. Use the tire's air as back pressure to unclog injector's feed line.
- Ensure air-compressor is charged. The air-compressor must have higher PSI than the half-deflated tire.

Counteract Balancing Beads, Inc.

70 Watson Parkway S. Unit #8, Guelph, Ontario, N1L 0C3

www.counteractbalancing.com

(519) 837-3331 or 1800 572 3088